

# ErP Power Mode Information Sheet

Number: 14-005

Revision: 1



## Phaser 3320

Device Type: Printer  
ErP Equipment Type: Other Networked Equipment

### POWER SUPPLY

Voltage (Volts) 230  
Output Rating (Watts) 805

### POWER MODE

	Power (Watts)	Default Period (Minutes)
Active	513.6	Not applicable
Ready/Standby	43.5	0
Sleep 1	3.1	1
Plugged In Off	0.0	Not applicable
Networked Standby - All	3.1	Not applicable
Networked Standby - USB	2.8	1
Networked Standby - Ethernet	3.0	1
Networked Standby - Wireless	2.8	1

### GUIDANCE – WIRELESS PORT

1. Deactivation
  - Insert Ethernet cable
2. Activation
  - Remove Ethernet cable

For more information about Xerox environmental programs in *North America*, refer to: [www.xerox.com/Environment](http://www.xerox.com/Environment)  
For more information about Xerox environmental programs in *Europe*, refer to: [www.xerox.com/environment\\_europe](http://www.xerox.com/environment_europe)

Xerox Corporation provides Power Mode Information Sheets in response to the provisions of ErP Directive 2009/125/EC with regard to eco-design requirements for standby, off mode power consumption of applicable networked printers according to Commission Regulations (EC) No 1275/2008 of 17 December 2008 and (EU) No 801/2013 of 22 August 2013

[Form Rev-1g]