ErP Power Mode Information Sheet

Number: 16-003
Revision: 1

xerox

WorkCentre 3345

Device Type   Multifunction Device
ErP Equipment Type: Other Networked Equipment

POWER SUPPLY
Voltage (Volts)   230
Output Rating (Watts)   700

POWER MODE

	Power (Watts)	Default Period (Minutes)
Active	698.8	Not applicable
Ready/Standby	45.6	0
Sleep 1	2.2	1
Plugged In Off	0.0	Not applicable
Networked Standby - All	2.3	Not applicable
Networked Standby - USB	2.2	1
Networked Standby - Ethernet	2.3	1
Networked Standby - Wireless	2.2	1
Networked Standby - FAX	2.2	1

GUIDANCE – WIRELESS PORT

1. Press **Login**. Log in as **admin** / **1111**
2. Press **Machine Status**
3. Scroll down to **Network Settings**. Touch **Network Settings**
4. Touch **Network Connectivity**
5. Touch the arrow on right to open the **Wired / Wireless** selection option window.
6. Select **Wired** to disable wireless.
7. Select **Wireless** to enable wireless. Select the desired wireless network and then enter the network password.